

MEN'S GARMENT SIZING INFORMATION

Men's Pants - Classic Casual, Workwear and Versa Collections

Size	30	31	32	33	34	35	36	38	40	42	44	46	48	50	52	54	56	58	60	62	64
Waist	31-33"	32-34"	33-35"	34-36"	35-37"	36-38"	37-39"	39-41"	41-43"	43-45"	45-47"	47-49"	49-51"	51-53"	53-55"	55-57"	57-59"	59-61"	61-63"	63-65"	65-67"

Men's Pant Fits

RELAXED FIT | Relaxed fit pants and jeans are cut to provide extra room in the seat and thigh. This style is roomier than regular fit.

REGULAR FIT | This style is considered the "middle of the road" or "average fit." Regular fit pants fall in between relaxed fit and a slim fit.

Men's Workwear & Classic Shirts

Size	Neck	Chest
Small	15"-15½"	41"-43"
Medium	16"-16½"	45"-47"
Large	17"-17½"	49"-51"
XL	18"-18½"	53"-55"
2XL	19"-19½"	57"-59"
3XL	20"-20½"	61"-63"
4XL	21"-21½"	65"-67"
5XL	22"-22½"	69"-71"

Men's Versa Shirts


Size	Neck	Chest
Small	15"-15½"	37½"-39½"
Medium	16"-16½"	41½"-43½"
Large	17"-17½"	45½"-47½"
XL	18"-18½"	49½"-51½"
2XL	19"-19½"	53½"-55½"
3XL	20"-20½"	57½"-59½"
4XL	21"-21½"	61½"-63½"
5XL	22"-22½"	65½"-67½"

Men's Coveralls

Alpha	Small	Medium	Large	XL	2XL	3XL	4XL	5XL							
Body Chest	36-38"	40-42"	44-46"	48-50"	52-54"	56-58"	60-62"	64-66"							
Garment Chest	44-46"	48-50"	52-54"	56-58"	60-62"	64-66"	68-70"	72-74"							
Numeric	36	38	40	42	44	46	48	50	52	54	56	58	60	62	64
Garment Chest	45-47"	47-49"	49-51"	51-53"	53-55"	55-57"	57-59"	59-61"	61-63"	63-65"	65-67"	67-69"	69-71"	71-73"	73-75"

Note: Regular height is 5' 8" - 6"; Tall is 6' 2" - 6' 4". Long measures 2" longer overall and 2" longer in the sleeves.

HOW TO MEASURE



All numbers listed above are measurements of the garment unless labeled with 'Body'.

NECK | Select a collared shirt that fits you well. Lay the collar flat and measure from the far end of the button hole to the button. Round up to the nearest inch for your neck measurement.

CHEST | Measure just under arms and across shoulder blades at the widest part of your chest. Be sure the tape measure is parallel to the floor. If waist is greater than chest measurement, use waist measurement.

WAIST | At your natural waistline, measure where your pants would normally ride. For an accurate measurement, do not measure over other clothing.

INSEAM | Without shoes; measure on the inside of your leg, from crotch to below your ankle.

Note: Due to the nature of flame resistant fabrics, pants will shrink approximately 1" in length during the first 25 washings, and will shrink a total of 2" in length during the first 50 washings.

For more information, visit

www.TyndaleUSA.com/fr-clothing-safety-library/frequently-asked-questions/frc-sizing-faqs/

